



Once you calculate the misclose, you should look at the Bearing of your misclose. The bearing of the misclose closer to the bearing of the line is how you know which line the error is made. Here bearing of misclose is equal or similar to BC Line. It is easier to find error if you draw in CAD